1958-59 Chevrolet Apache Extended Headlamp Buckets

Reuse the factory inner buckets and mounting hardware. The kit includes a pair of extended buckets and new aiming screws.



Stand sizes

0 mm	Start here	**-2 mm**	Test if needed	**-4 mm**	Test if needed

1. Remove the factory outer buckets.

Switch off the lights and disconnect the negative battery cable. Remove the trim and lamps, then unbolt the outer buckets. Keep the inner buckets and reusable hardware with their original sides.

2. Install the 0 mm stands.

Use the supplied 8-32 screws. For lettered brackets, match each letter to itself: **A to A, B to B, C to C, D to D.**

> **Older kits: Look for numbers on the brackets**
> If your brackets are marked 1–4, use this key instead: **1 to A, 2 to B, 3 to C, 4 to D.**

3. Test-fit the trim ring.

Transfer the inner buckets and original hardware. Use the new aiming screws. Set the extended buckets in place and hold the trim ring in place before tightening. If it doesn’t sit evenly, try a -2 mm or -4 mm stand and check again. The ring should sit snug without using the screws to pull it into place.

4. Reassemble and aim the lights.

Secure the buckets, reinstall the lamps and trim, and make sure the wiring isn’t pinched. Reconnect the battery, test both beam settings, then aim the headlamps.

Have questions? Contact us support@dapperlighting.com | (833) 327-7371